

INTELLIGENT ELECTRONIC LOCK SIMPLE OPERATION MANUAL





PRODUCT PARAMETERS

Basic parameters

Category	Detailed technical parameters
working voltage	INPUT: DC 6V
Standby power supply voltage	USB Micro Interface power supply: DC 5~7V
Matching fingerprint sensor type	Semiconductor sensorv
Password keyboard	Capacitive touch keyboard
Number of keys	12Key (0~9,#Key to confirm ,* key to cancel)
Language mode	Chinese or English voice navigation
Quiescent current	≤70uA
Dynamic current	≤300mA
Drive output	Direct
Driving load capacity	≤300mA
Low voltage alarm voltage	≤4.8V(When the power supply voltage is lower than the standard 80±5%, it indicates that the battery is dead)
Fit card type	IC卡
Attendance Record	10000 Strip
working temperature	-25°C~+65°C
Storage temperature	-40°C~+80°C
Working humidity	5~95%RH (No condensation)
Total capacity	1000
Single password	1000
Single card	1000
Single fingerprint	100 Pieces

1. Restore factory settings

Initialization is through the hole above the rear lock button, press for more than 6 seconds, and the system prompts [initialization is successful], and the system returns to the factory state

2. Normally open setting

After verifying the key or fingerprint unlocking, press the "2, 8" key to enter the normally open mode, voice broadcast "has entered the normally open mode", and then the system enters the sleep state; Any valid key will automatically exit the normally open mode after unlocking.

3. Quick operation


A: "0#"One key lock

4. Function test

Press 1 # (input administrator password), press #, confirm and press 0 to open, press * to exit



Bluetooth connection steps



Open "graffiti app" Click Add device



Select "door lock" fromthe "security monitoring "option " (Bluetooth) "



Displayed by scanning "Bluetooth lock" click orangeAdd device with color "+" number



Orange after successful Click the pen behind addition" + "The number the Bluetooth lock to will turn green



modify the lock name



After adding, press and hold to unlock





The top three are administrators Please register a 6-digit administrator password Easy to operate by mobile phone



Member management
Door opening record
Fingerprint management
Password management
Door card management
Door lock voice
Volume navigation
Temporary password









Long press the initialization key to restorethe factory settings of the system. The first three users are administrators.

